

Instructions for operation of OSD

Model: 28" 16:9 MDM Plus Vertical.

When the monitor starts its operation connected with the computer unit, a window is appearing with the logo NovaProductions lasting 50secs while the monitor operates on blanking screen mode. Then, the game makes its appearance. In case we do not want to wait 50 secs we exit from blanking screen mode by pressing one of the four buttons.

[MENU – SELECT – (+) – (-)].

The adjustments:

The next step is to adjust the monitor, by pressing the button MENU. Then on the screen we have the appearance of CONTRAST (see table 1, first adjustment). We select the desired value and we proceed to the next adjustment which is BRIGHTNESS by pressing the button SELECT. In order to store the adjustments we have to press the MENU button. Please note that if we adjust the monitor and we switch it off without pressing the menu button, the adjustments will not be stored and the monitor will start with the previous adjustments.

Please note that STATUS SCREEN remains as it was in the previous version (Horizontal operation)

In the new version of OSD, we added 3 new adjustments, 2 of which are adjusted automatically while the 3rd is the last on the selections PINCUSHION BALANCE.

In the following table you will find the suggested adjustments:

Please note that these adjustments refer to the CRT W66ERF041X044.

<u>Symbol</u>	<u>Description</u>	<u>Price:</u>
	CONTRAST	180
	BRIGHTNESS	085
	HORIZONTAL SIZE	065 (063~075) *
	HORIZONTAL SHIFT	071 (069~073) *
	VERTICAL SIZE	060 (060~065) *
	VERTICAL SHIFT	065 (063~067) *
	TRAPEZOID	063
	PINCUSHION	019 (019~021) *
	PARALLELOGRAM	034
	VERTICAL LINEARITY	020
	VERT. CENT. LIN.	030
	PINCUSHION BALANCE	034

*In these type of adjustments there is a slight tolerance from monitor to monitor.